


Ituo-Varia
SimpleSpec 200.56™


| Installation
Manual




Contents Overview

(x2)


3/8" Varia Panel

(x2)


Vertical Post,
1 Glazing Channel, 96"
0-15-2183

(x1)


Vertical Post,
2 Glazing Channels, 96"
0-15-2181

(x4)


1/2" Glazing
Channel
3-15-2009

(x3)


Half Wall Top Cap
Straight Run, End

(x3)


Installation Template
Baseplate Guide
3-15-2160

(x2)


Installation Template
Spacer Guide
3-15-2347

(x3)


VHB Tape
3-15-2171

(x3)


Baseplate KIT
3-15-2110-K

(x3)

+

(x6)


+

(x6)


Baseplate
3-15-2110

Baseplate Cover
3-15-2114


Screw
3-15-2308

(x3)

Baseplate Universal
Anchoring KIT
3-15-2119-K

(x12)

+


(x12)

M8x105 Concrete
Lag Screw
3-15-2309

Hex Head Wood
Lag Screw
3-15-2310

Contents Overview


(×1)



Half Wall Center Post Attachment KIT
3-15-2163-K

=


(×2)



Half Wall Top Rail Straight Adapter Plate
3-15-2163

+


(×4)



Screw
3-15-2303


+

(×4)



Screw
3-15-2302


(×2)



Half Wall End Post Attachment KIT
3-15-2164-K

=


(×2)



Half Wall Top Rail Straight Adapter Plate
3-15-2164

+


(×8)



Screw
3-15-2303

+

(×4)



Screw
3-15-2302

Add a Set of 2 Panels

(×2) 3/8" Varia Panel

(×2) Vertical Post, 2 Glazing Channels, 96" 0-15-2183

(×4) 1/2" Glazing Strip, 96" 3-15-2009

(×2) Baseplate KIT 3-15-2110-K


(×2) Baseplate Universal Anchoring KIT 3-15-2119-K

(×2) Installation Template Baseplate Guide 3-15-2160


(×2) Installation Template Spacer Guide 3-15-2347

(×2) Half Wall Center Post Attachment KIT 3-15-2163-K

(×1) Half Wall Top Cap Straight Run




Overview




Installation

Required Tools



1 Drill Pilot Holes (×12)

- a** Baseplate templates (3-15-2160) will be provided. The Baseplate template has hole locations for drilling. Spacers will also be provided, unique to this configuration; cut to size based off post dimensions in the quoting phase.



- b** Following the Iltuo Installation Template, drill pilot holes. Use appropriate pilot hole diameter and depth for the type of substrate you are fastening to.


**3form stocks the drill bits required for the concrete and wood pilot holes. If you wish to purchase a drill bit, please contact your 3form sales representative.*

Substrate	Ø	Drill Bit	Depth	Anchors
Concrete	8mm	3-15-2350	min 4.3"	3-15-2309
Wood	3/16"	3-15-2335	min 3.5"	3-15-2310


Installation

2 Assemble Vertical Posts (×3)


- a Cut Glazing Channel (3-15-2009) to 3' 11 1/8" lengths. (×12)



- b Assemble Vertical Posts (0-15-2182). (×2)




Assemble Vertical Post (0-15-2181). (×1)




Installation

3 Secure First Vertical Post to Floor

Use hammer drill to secure post.



4 Install Varia Panel




5 Install Remaining Posts and Panels

Repeat Steps 3-4 for all remaining posts and panels.

Installation

6 Install Adapter Plates on Posts



7 Install Top Caps

