



Ituo-Varia
SimpleSpec 200.60™

| Installation
Manual





Contents Overview




(x1)


ILTUO T Base Plate KIT
3-15-2120-K



Overview




Required Tools



Installation

1 Drill Pilot Holes (×24)

- a** Base plate templates (3-15-2160) will be provided. The base plate template has hole locations for drilling. Spacers will also be provided, unique to this configuration; cut to size based off post dimensions in the quoting phase.



- b** Following the ILTUO Installation Template, drill pilot holes. Use appropriate pilot hole diameter and depth for the type of substrate you are fastening to.


**3form stocks the drill bits required for the concrete and wood pilot holes. If you wish to purchase a drill bit, please contact your 3form sales representative.*

Substrate	Ø	Drill Bit	Depth	Anchors
Concrete	8mm	3-15-2350	min 4.3"	3-15-2309
Wood	3/16"	3-15-2335	min 3.5"	3-15-2310

Installation


2 Assemble Vertical Posts

Assemble the Vertical Posts as shown below.




3 Secure ILTUO Vertical Post with T-Configuration to Floor

Use hammer drill to secure post.




Installation

4 Install First 2 Varia Panels




5 Secure (×2) ILTUO Vertical Posts with 1 Glazing Channel to Floor




Installation

6 Install Remaining Posts and Panels




7 Assemble ILTUO Cantilevered Top Rail T Kit 3-15-2124-K

a




b




Installation

7 Assemble ILTUO Cantilevered Top Rail T Kit 3-15-2124-K cont...

C



8 Connect Top Rail Assembly to Vertical Posts



Installation

9 Attach End Caps

