


Ready To Go

SimpleSpec 100.08™



















Installation Manual



For more information, please visit 3-form.com or call 800.726.0126


JUNE 2017 | MAN-RTG-100-08 | REV 001 © 2017 3form, Inc. All rights reserved.

Contents Overview

(×2)		(×4)		=	<div><div> (×4) Stiffener/Handle 3-15-1645</div><div>+</div><div> (×24) Countersunk Socket Cap Screw M3 × 30mm 3-15-0798</div></div>			
(×2)		(×2)		=	<div><div> (×2) "U" Guide with Rollers 3-15-1621</div><div>+</div><div> (×4) 3/16" × 1-1/4" Fastener 3-15-0841</div></div>			
(×2)		(×2)		=	<div><div> (×2) "U" Guide Receiver 3-15-1672</div><div>+</div><div> (×4) 3/16" × 1-1/4" Fastener 3-15-0841</div></div>			
(×4)		(×4)		=	<div><div> (×4) Roller</div><div>+</div><div> (×4) Fixation Plate</div><div>+</div><div> (×8) Screw</div></div>			
(×4)								
	Top Bracket 3-15-1750							


Overview

The 100.08 door system from 3form is a set of bypassing unframed doors with the weight borne at the header. It uses a concealed track and roller system that creates an aesthetically appealing, versatile door system with excellent functionality. 100.08 puts emphasis on the material it holds, making a beautiful, functional solution for your installation.




Pre-Installation


Required Tools




Drill




Chop Saw



Metric Allen Wrenches



Wrench




Level

Installation

1 Attach Handles


* Complete this step for both doors.



Installation

2 Attach Top Brackets


** Complete this step for both doors.*



Installation

3 Attach Roller Fixation Plates

** Complete this step for both doors.*





Installation

4 Insert Top Rollers and Bumpers



** Complete this step for both tracks.*

- a** Cut both tracks to length for opening size using chop saw with blade for cutting aluminum.




5 Install Top Tracks

Anchor every $\pm 18"$ O.C. to substrate.



Installation


6 Install Floor Guides and Receivers




Installation

7 Attach Doors


a



b Level the door by adjusting the top roller hanging bolt with a wrench.




c Once level, tighten nut.



Installation

8 Attach Valances

Cut valances (3-15-1751) to length and snap in place.



9 Adjust Bumpers

Adjust bumpers (3-15-1761 - 2 per track) installed in Step 4c to stop the doors from hitting the wall.

